








Datrend Systems Inc.
Unit 130 - 4020 Viking Way, Richmond, BC, Canada V6V 2L4
Phone: 604-291-7747 Fax: 604-294-2355 Toll Free: 1-800-667-6557
E-mail: customerservice@datrend.com Web: www.datrend.com

ITEM NO.	DESCRIPTION
1	Configured Standard Tablet For vPad-IN Incubator Tester (P/N:7050-103)
2	Incutest Temperature Sensor Quadrant Unit (P/N:7400-490)
3	vPad-IN Temperature Sensor Central Unit (DAT Unit, P/N: 7400-498)
4	Incutest Sound Level Sensor Assembly (P/N: 7400-492)
5	Incutest Air Flow Sensor Assembly (P/N: 7400-494)
6	Incutest Humidity Sensor Assembly (P/N: 7400-493)
7	Incutest Temperature Probe Assembly (P/N: 7400-495)
8	Incutest Mattress Temperature Sensor Assembly (P/N: 7400-499)
9	Power Supply, 15W WPI, 100-240VAC, 9VDC/1700mA, c/w EIAJ Connector (P/N: 3000-611)
10	Micro-B USB Cable For Tablet (P/N: 3140-478)
11	DC Charger For Tablet (P/N: 3000-080 or 3000-081 or 3000-082 or 3000-083)
12	Extension Cable, MiniDin 6P PS/2 M-F, 12', Black (P/N: 3140-056)
13	Incutest Positioning Frame Cross Bar (P/N: 5500-520)
14	Incutest Positioning Frame T-Bracket Assembly (P/N: 7400-496)
15	Incutest Positioning Frame Long Bar (P/N: 5500-519)
16	Incutest Oven (P/N: 8000-494)
17	Power Supply, 15W WPI, 100-240VAC, 9VDC/1700mA, c/w EIAJ Connector (P/N: 3000-611)
18	Kit, AC Input Blade Set For Power Supply (for Item#17, P/N: 7500-490)
19	Kit, AC Input Blade Set For Power Supply (for Item#9, P/N: 7500-490)

vPad-IN Incubator Tester Quick Start Guide



vPad-IN Incubator Tester Quick Start Guide

